

# Zi Predictive Text Suite for Series 60 User Manual

## eZiText & eZiTap

### How to get started

You may immediately start using eZiText in any field or application requiring text entry.

eZiText provides one-touch text entry and full word prediction for the fastest input system.

eZiTap provides multi-tap entry with full word prediction so that you can have the speed benefits of predictive text within the familiarity of the generic multi-tap entry.

They work in any application which requires text entry,<sup>1</sup> including messaging, phonebook, calendar, to-do, mobile browsing input fields and more. With both input systems included on your handset, you have the flexibility to select the input system and features you prefer to use on the 12-button keypad.

For your convenience, eZiText is enabled for immediate use. To switch to eZiTap, press the pen icon key while in any text input field and change the "Prediction Mode" from eZiText to eZiTap.

### Entering words

eZiText text entry and word prediction: **Entering the word "welcome"**

1. Select the letters "w", "e", "l", "c" by entering key sequence 9, 3, 5, 2
2. The full word "welcome" appears in the text entry area
3. If this is not your target word use the \* key to navigate to other candidates with the same key presses


**NOTE: with multiple candidate display enabled simply navigate with the down arrow key to other candidates**

4. Select the fully predicted word with the 0 key

**NOTE: see page 2 for eZiTap entry instructions.**

Enter a word with a contraction in eZiText: **Entering the word "we're"**

1. Select the letters "w" and "e" with key sequence 9, 3
2. Select the 1 key to denote punctuation required
3. Select the next letter "r" with the 7 key
4. Select the fully predicted word with the 0 key



<sup>1</sup>eZiTap and eZiText are not available when the text input field is for name creation of a folder or a file in any application such as rename an image file.

Lingo entry in eZiText: **Entering the lingo word "LOL" (a SMS short cut for the term "laughing out loud")**

1. Select the 5 key
2. Navigate to letter "L" with three presses of the \* key
3. Joystick right to select the letter "L"
4. Select the 6 key
5. Navigate to letter "O" with three presses of the \* key
6. Joystick right to select the letter "O"
7. Select the 5 key
8. Navigate to letter "L" with three presses of the \* key
9. Joystick right to select the letter "L"

The lingo word "LOL" will now be automatically stored for future prediction.

**NOTE: with multiple candidate display enabled simply use the down arrow key to navigate to and select a letter from a specific key. In eZiTap, you may enter in lingo words in multi-tap at any time.**

Personal word entry: **Entering a personal word, such as the last name "Mensinga"**

1. Select the letters for the name "Mensinga". Key sequences 6, 3, 6, 7, 4, 6, 4, 2
2. eZiText will prompt you to spell the word; select Spell? With the left soft key (this is the key below the screen, on the left)
3. Use multi-tap to enter in this personal word

The name "Mensinga" will be automatically stored for future prediction.

**NOTE: personal words also can be added manually through the features menu. Select the Pen key, then select Spell? from the menu and enter in the new word. With eZiTap, you may enter personal words in multi-tap at any time.**

Dual language text entry for eZiText and eZiTap

You have the capability for text entry and prediction from two language dictionaries without having to manually switch between languages each time. This is useful for users who regularly communicate in multiple languages between friends, family, and colleagues.

You may select from any of the installed languages. Additional languages such as French German, Swedish and Spanish may be purchased and installed separately. Candidates will be predicted first from the primary language dictionary and then from the secondary language dictionary. For example, if English is set as the primary language and French as the secondary language, you will see English candidates such as "bib" and "challenge" predicted before French candidates such as "bibliothèque" with the same key presses.



eZiTap text entry and word prediction: **Entering the word "welcome"**

1. Press the 9 key once for letter "w"
2. Press the 3 key twice for letter "e"
3. Press the 5 key tree times for letter "l"
4. Press the 2 key three times for letter "c"
5. The full word "welcome" appears in the text entry area
6. If this is not your target word use the \* key to navigate to other candidates with the same key presses


**NOTE: with multiple candidate display enabled simply navigate with the down arrow key to other candidates.**

7. Select the fully predicted word with the 0 key

## Features menu

The features menu is accessible while in text input mode. Open the menu by selecting the Pen key. This key is illustrated with a pen graphic in the middle of the key.

**NOTE: Before you begin text entry with eZiText or eZiTap for the first time, you are encouraged to review the features menu and configure it to your preference.**




Features	Function
<b>Spell?</b>	Manual entry of new personal words in the Personal Dictionary (PD) for future prediction <ul style="list-style-type: none"> <li>• Select Add for adding new personal words into the PD for subsequent prediction</li> <li>• Select Edit for editing the words stored in the PD</li> <li>• Select Delete One to remove one selected word from the PD</li> <li>• Select Delete All to clear the PD</li> </ul> <b>NOTE: A Spell? prompt will also automatically appear during text entry if a word is not recognized (eZiText mode only).</b>
<b>Prediction</b>	<ul style="list-style-type: none"> <li>• Select On to make predictive text entry function available (defaulted on)</li> <li>• Select Off to use multi-tap entry mode only</li> </ul>
<b>Prediction Mode</b>	Switch between eZiText and eZiTap (defaulted to eZiText) <b>NOTE: This option is displayed for selection only when Prediction is on.</b>
<b>Full Word Prediction</b>	Turn on/off the full word prediction function (defaulted on) <ul style="list-style-type: none"> <li>• Select On for prediction of whole words (such as prediction of "tomorrow" with entry of 8, 6, 6, 6)</li> <li>• Select Off and prediction will be limited to the number of keys entered (such as prediction of "tomo" with entry of 8, 6, 6, 6)</li> </ul> <b>NOTE: This option is displayed for selection only when eZiText is selected.</b>
<b>Predict On</b>	Prediction of whole words can be set to display after entry of the 2nd letter, 3rd letter, or 4th letter. The default is prediction after the 4th letter.
<b>Candidate Display</b>	Select Single Inline (default) or Multiple candidate display mode.
<b>Language</b>	The default setting is English however additional add-on languages can be purchased. If additional languages are installed, switch between language dictionaries for prediction.
<b>Second Language</b>	Select a secondary language for dual language text entry and prediction (defaulted to none), if additional languages have been purchased and installed.
<b>Learning</b>	This option is for the Used Word Dictionary (UWD) function. The UWD stores learned and commonly used words entered by you and predicts these personal words before candidates from the language dictionary with the same key sequence (defaulted on). <ul style="list-style-type: none"> <li>• Select On to turn the UWD on</li> <li>• Select Off to turn the UWD off</li> <li>• Select Reset Learning to delete all UWD records</li> </ul>
<b>Predict Next Word</b>	This option allows the UWD to use learned phrases to propose the next word without any additional key press (defaulted off). <ul style="list-style-type: none"> <li>• Select On to turn prediction of the next word on</li> <li>• Select Off to turn prediction of the next word off</li> </ul>
<b>Auto Spacing</b>	<ul style="list-style-type: none"> <li>• Select ON to automatically insert a space when selecting a predicted word (default)</li> <li>• Select Off to turn this feature off</li> </ul>
<b>Auto Capitalization</b>	<ul style="list-style-type: none"> <li>• Select On to capitalize the next character after a full stop punctuation followed by a space (default)</li> <li>• Select Off to turn this feature off</li> </ul>
<b>Insert Smilies</b>	Choose this option to display a pre-defined smiley table for selection.
<b>Help</b>	Provides a brief introduction on how to use eZiText and eZiTap (use joystick right key to navigate among help files).
<b>Info on Product</b>	Provides general information on eZiText and eZiTap.

## Keypad guide

Key(s)	Function
<b>0 key</b>	<b>Space:</b> Enter space between text entry. <b>Candidate Selection:</b> Within text entry and prediction, select a candidate and automatically insert a space afterwards.
<b>1 key</b>	<b>Smart Punctuation</b> key for punctuation input (see page 1 for contraction entry instructions).
<b>0, 1 – 9 keys</b>	<b>Number Entry in Predictive Mode:</b> Enter the number on a particular key with a long key press (hold key for 3+ seconds).
<b>* key</b>	<b>Symbols Table Lookup:</b> Short key press between text input of words or long key press during text entry and prediction. <b>Inline Candidate Navigation:</b> In single candidate display mode, within text entry and prediction, short key press to navigate to other candidates with the same sequence of key presses.
<b># key</b>	<b>Case Sensitive Selection:</b> With short key press, switch between lower case, title case and upper case. <b>Input Mode Switch:</b> With long key press, switch between predictive text, multi-tap. <b>Predictive mode icon:</b> Icon in top right corner of screen denotes case sensitive and text entry modes. <b>eZiText mode icon</b> ("TEXT" letters in lower case, title case and caps-lock case indicated current case sensitivity). <b>eZiTap mode icon</b> ("TAP" letters in lower case, title case and upper case indicate current case sensitivity). <b>Multi-tap mode icon</b> ("ABC" letters in lower case, title case and upper case indicate current case sensitivity). <b>Numeric mode icon</b> ("123") <b>NOTE: eZiText and eZiTap can not be switched by long key pressing the # key. Use the features menu located on the Pen icon key to switch between input modes under "Prediction Mode".</b>
<b>Joystick right</b>	<b>Candidate Selection</b> without space inserted after word.
<b>Joystick left</b>	<b>Partial Word Selection:</b> Select the underlined portion of the predicted word only (the underlined letters of the word indicated the number of key presses entered).
<b>Joystick up/down</b>	<b>Multiple Candidate List Navigation:</b> In multiple candidate display mode, navigate among candidates within the candidate box.
<b>Joystick centre</b>	<b>Candidate Selection:</b> In multiple candidate display mode, select a displayed candidate with this key. A space will be automatically inserted after the selected word. Alternatively, use the 0 key.
<b>C key</b>	<b>Clear letters</b> and words at any time.
<b>Pen Key</b>	Short cut key to text input <b>Features Menu</b> .

## Turning suite on/off

1. Select the Zi loader icon from the phone's main menu.
2. Select Prediction Mode and the options eZiText, eZiTap and None will appear.
3. Select None to turn the suite off.



**For product updates and more information, visit [www.zicorp.com](http://www.zicorp.com) or e-mail [info@zicorp.com](mailto:info@zicorp.com).**

© 2005 Zi Corporation. All Rights Reserved. Zi, eZiTap and eZiText are either trademarks or registered trademarks of Zi Corporation. All other trademarks are the property of their respective owners.